

# CONTROL PANEL CHART

Burner	Compatible Control Panel(s)	BTU's		Gas Fittings
		LP	NG	
CFP20/BI16	<u>Standard:</u> VCSV-CP (6.38" X 3.5") <u>Options:</u> VCSV-CP-SQ (6.38" X 6.38"), or VCSV-DIY-CP	55K	55K	½" OD Flare
CFP30/BI28	<u>Standard:</u> VCSV-CP (6.38" X 3.5") <u>Options:</u> VCSV-CP-SQ (6.38" X 6.38"), or VCSV-DIY-CP	105K	106K	½" OD Flare
CFP1224/BI719	<u>Standard:</u> VCSV-CP (6.38" X 3.5") <u>Options:</u> VCSV-CP-SQ (6.38" X 6.38"), or VCSV-DIY-CP	55K	55K	½" OD Flare
CFP1242/BI737	<u>Standard:</u> VCSV-CP (6.38" X 3.5") <u>Options:</u> VCSV-CP-SQ (6.38" X 6.38"), or VCSV-DIY-CP	80K	80K	½" OD Flare
CFP1264/BI757	<u>Standard:</u> VCSV-CP (6.38" X 3.5") <u>Options:</u> VCSV-CP-SQ (6.38" X 6.38"), or VCSV-DIY-CP	100K	100K	½" OD Flare
CFP1272/BI766	<u>Standard:</u> VCSV-CP (6.38" X 3.5") <u>Options:</u> VCSV-CP-SQ (6.38" X 6.38"), or VCSV-DIY-CP	125K	125K	½" OD Flare
CFP1284/BI778	<u>Standard:</u> VCSV-CP (6.38" X 3.5") <u>Options:</u> VCSV-CP-SQ (6.38" X 6.38"), or VCSV-DIY-CP	140K	140K	½" OD Flare
CFP1296/BI790	<u>Standard:</u> VCSV-CP (6.38" X 3.5") <u>Options:</u> VCSV-CP-SQ (6.38" X 6.38"), or VCSV-DIY-CP	165K	165K	½" OD Flare
CFP12108/BI7102	<u>Standard:</u> VCSV-CP (6.38" X 3.5") <u>Options:</u> VCSV-CP-SQ (6.38" X 6.38"), or VCSV-DIY-CP	180K	180K	½" OD Flare
CFP12120/BI7114	<u>Standard:</u> VCSV-CP (6.38" X 3.5") <u>Options:</u> VCSV-CP-SQ (6.38" X 6.38"), or VCSV-DIY-CP	200K	200K	½" OD Flare
WV-56 (DSI Only)	See DSI Controls	150K	149.5K	½" OD Flare
CF-DSI-NG CF-DSI-LP	<u>Standard:</u> 6.38" X 3.5" ON/OFF Control Panel <u>Options:</u> DSI-DIY-CP, 4HRTC, WSES-CP, or 4HRTES-CP	-	-	½" OD Flare

- For custom burners, please contact OGC for any questions
- The maximum distance that a VCSV control panel can be located from the center of burner is 36". Anything that exceeds this must operate on a DSI.
- All linear burners larger than a CFP1264/BI757 and operating on a VCSV must have two (2) control panels. This includes the CFP12120/BI7114.

