

RENEGADE FIRE TABLE WITH CF-12 BURNER: INSTRUCTION ADDENDUM

ATTENTION: The following information in the Renegade Fire Table manual is no longer accurate.

Page 4: An NF-16 burner is no longer included and is replaced with a CF-12 burner that will come in a separate box. An additional burner support ring and smaller media retention pad is now included. See Image 1.

Page 6: Before installing the gas connections of the burner, place burner support ring into fire table as shown in Image 2.

Then install burner in burner support ring as shown in Image 3.

Page 13: Ensure that smaller media retention pad is positioned on burner so that igniter sits in the ovular slot of retention pad. See Image 4.




Image 1



Image 2



Image 3




Image 4

